


WIRING DIAGRAM FOR  
MILLER S.U.S. SET, 1930

incorporating

74E HEAD LAMP,  
with Dipping Switch.  
D.M.3G. DYNAMO  
6-volt  
or D.M.2. 4 volt




Inset shows wiring for  
D.M.3G. Dynamo of  
clock rotation, looking  
from driving end.

INDICATES EARTH OR  
FRAME CONNECTION.

DYNAMO CONNECTIONS  
FOR D.M.3G. CLOCK ROTATION

DYNAMO CONNECTIONS FOR  
D.M.3G. ANTI-CLOCK AND D.M.2.  
CLOCK AND ANTI-CLOCK  
ROTATION.

Where Dip Lite Switch is not  
fitted, Main Bulb Contact is  
connected to Contact No. 8.




⊕ INDICATES EARTH  
OR FRAME CONNECTION

WIRING DIAGRAM FOR  
3 LAMP SET WITH COIL IGNITION  
D.9.S.I. DYNAMO, INSTRUMENT

E SWITCH PANEL

H MILLER & CO LTD  
DRG No 822.30/12/31

WIRING DIAGRAM FOR 73E1  
HEAD LAMP WITH DIPLITE,  
COIL IGNITION & DM3G DYN



DRAWING NUMBER 900  
 H. MILLER & CO. LTD  
 J.W.G. 26-10-32